

CRUISER

Periodic Maintenance Chart

Periodic Inspection (Chassis Related Items)

FREQUENCY Operation (Chassis Items)	Whichever comes first ↓ Every	* Odometer Reading km x 1000						
		1	5	10	15	20	25	30
Clutch and drive train:								
Clutch operation (play, engagement, disengagement) - inspect		•		•		•		•
K Drive belt deflection - inspect		•	•	•	•	•	•	•
K Drive belt wear - inspect		•	•	•	•	•	•	•
Wheels and tires:								
Tire air pressure - inspect	year			•		•		•
Wheels/tires damage - inspect				•		•		•
Tire tread wear, abnormal wear - inspect				•		•		•
K Wheel bearing damage - inspect	year			•		•		•
Brake system:								
Brake fluid leak - inspect	year	•	•	•	•	•	•	•
K Brake hoses damage - inspect	year	•	•	•	•	•	•	•
Brake pad wear - inspect #			•	•	•	•	•	•
K Brake hose installation condition - inspect	year	•	•	•	•	•	•	•
Brake fluid level - inspect	6 month	•	•	•	•	•	•	•
Brake operation (effectiveness, play, drag) - inspect	year	•	•	•	•	•	•	•
Brake light switch operation - inspect		•	•	•	•	•	•	•
Suspensions:								
K Front forks/rear shock absorber operation (damping and smooth stroke) - inspect				•		•		•
K Front forks/rear shock absorber oil leak - inspect	year			•		•		•
K Swing arm pivot - lubricate						•		
K Uni-trak rocker arm operation - inspect				•		•		•
K Uni-trak tie rods operation - inspect				•		•		•
K Uni-trak rocker arm bearings - lubricate						•		
K Uni-trak tie rods bearings - lubricate						•		
Steering system:								
K Steering play - inspect	year	•		•		•		•
K Steering stem bearings - lubricate	2 years					•		
Electrical system:								
Lights and switches operation - inspect	year			•		•		•
Headlight aiming - inspect	year			•		•		•
Side stand switch operation - inspect	year			•		•		•
Engine stop switch operation - inspect	year			•		•		•
Chassis:								
Chassis parts - lubricate	year			•		•		•
Bolt and nuts tightness - inspect		•		•		•		•

Periodic Inspection (Engine Related Items)

FREQUENCY Operation (Engine Items)	Whichever comes first ↓ Every	* Odometer Reading km x 1000						
		1	5	10	15	20	25	30
Valve clearance - inspect						•		
Throttle control system (play, smooth return, no drag) - inspect	year	•		•		•		•
Idle speed - inspect		•		•		•		•
K Fuel leak (fuel hose and pipe) - inspect	year	•		•		•		•
K Fuel hoses damage - inspect	year	•		•		•		•
K Fuel hoses installation condition - inspect	year	•		•		•		•
Coolant level - inspect		•		•		•		•
Coolant leak - inspect	year	•		•		•		•
Radiator hose damage - inspect	year	•		•		•		•
Radiator hoses installation condition - inspect	year	•		•		•		•
Air suction system damage - inspect				•		•		•

CALL FOR BEST PRICE

Periodic Replacement

FREQUENCY Change/Relacement Items	Whichever comes first ↓ Every	* Odometer Reading km x 1000				
		1	5	10	15	20
K Air cleaner element # - replace		every 18 000 km				
Engine oil # - change	year	•	•	•	•	•
K Oil filter - replace	year	•	•	•	•	•
K Fuel hoses - replace	4 years					•
K Coolant - replace - change	3 years				•	
K Radiator hoses and O-rings - replace	3 years				•	
K Brake hoses - replace	4 years					•
K Brake fluid (front and rear) - change	2 years			•		•
K Rubber parts of master cylinder and caliper - replace	4 years					•
K Spark plug - replace				•		•

K : Should be serviced by an authorized dealer

* : For higher odometer readings, repeat at the frequency intervals established here

: Service more frequently when operating in severe conditions: dusty, wet, muddy, high speed, or frequent starting/stopping

Synthetic Oil Extra

KAHUNA
Powersports

www.kahunapowersports.com

